

DCX 222 RM SIG Power Supply

Operating Manual

Branson Ultrasonics Corp.
120 Park Ridge Road
Brookfield, CT 06804
(203) 796-0400
<http://www.bransonultrasonics.com>

Manual Change Information

At Branson, we strive to maintain our position as the leader in ultrasonics plastics joining, metal welding, cleaning and related technologies by continually improving our circuits and components in our equipment. These improvements are incorporated as soon as they are developed and thoroughly tested.

Information concerning any improvements will be added to the appropriate technical documentation at its next revision and printing. Therefore, when requesting service assistance for specific units, note the Revision information found on this document, and refer to the printing date which appears on this page.

Copyright and Trademark Notice

Copyright © 2026 Branson Ultrasonics Corporation. All rights reserved. Contents of this publication may not be reproduced in any form without the written permission of Branson Ultrasonics Corporation.

Mylar is a registered trademark of DuPont Teijin Films.

Loctite is a registered trademark of Loctite Corporation.

WD-40 is a registered trademark of WD-40 Company.

Windows 10, Windows 11, and Microsoft Edge are registered trademarks of Microsoft Corporation.

Google Chrome is a trademark of Google LLC.

Other trademarks and service marks mentioned herein are held by their respective owners.

Foreword

Congratulations on your choice of a Branson Ultrasonics Corporation system!

The Branson DCX 222 RM SIG Power Supply system is process equipment for the joining of plastic parts using ultrasonic energy. It is the newest generation of product using this sophisticated technology for a variety of customer applications. This Operating Manual is part of the documentation set for this system, and should be kept with the equipment.

Thank you for choosing Branson!

Introduction

This manual is arranged into several structured chapters which will help you find the information you may need to know to safely handle, install, set up, program, operate, and/or maintain this product. Please refer to the [Table of Contents](#) and/or the [Index](#) of this manual to find the information you may be looking for. In the event you require additional assistance or information, please contact our Product Support department (see [1.3 How to Contact Branson](#) for information on how to contact them) or your local Branson representative.

Table of Contents

Chapter 1: Safety and Support

1.1	Safety Requirements and Warnings	2
1.2	General Precautions	4
1.3	How to Contact Branson	6

Chapter 2: The Web Page Interface

2.1	Introduction	8
2.2	Models Covered	9

Chapter 3: Connecting to the Web Page Interface

3.1	Locating the Ethernet Port	12
3.2	System Requirements.	13
3.3	Point to Point Connection (Windows 10® or Windows 11®)	14

Chapter 4: The Web Page Interface

4.1	Web Page Interface Overview	18
4.2	Login	19
4.3	IP Setup	20
4.4	Weld Preset.	22
4.5	I/O Diagnostics	25
4.6	Seek & Weld Graphs.	27
4.7	Horn Signature	29
4.8	System Information	31
4.9	Alarm Log	32

Appendix A: Manual's Revisions

A.1	Manual's Revisions	36
-----	------------------------------	----

List of Figures

Chapter 1: Safety and Support

Chapter 2: The Web Page Interface

Chapter 3: Connecting to the Web Page Interface

Figure 3.1 DCX 222 RM SIG Power Supply	12
--	----

Chapter 4: The Web Page Interface

Figure 4.1 Web Page Interface Overview	18
Figure 4.2 Login	19
Figure 4.3 IP Setup Menu	20
Figure 4.4 Weld Preset Menu	22
Figure 4.5 I/O Diagnostics Menu	25
Figure 4.6 Seek & Weld Graphs Menu	27
Figure 4.7 Horn Signature Menu	29
Figure 4.8 System Information Menu	31
Figure 4.9 Alarm Log Menu	32

Appendix A: Manual's Revisions

Figure A.1 Manufacturing date on the Information label	36
Figure A.2 Location of the Information label on the back of the DCX 222 RM SIG Power Supply	37

List of Tables

Chapter 1: Safety and Support**Chapter 2: The Web Page Interface****Chapter 3: Connecting to the Web Page Interface****Chapter 4: The Web Page Interface**

Table 4.1	Web Page Interface Overview	18
Table 4.2	IP Setup Menu Option	20
Table 4.3	Weld Preset Menu Option	23
Table 4.4	I/O Diagnostics Menu Option	25
Table 4.5	Seek & Weld Graphs Menu Option	28
Table 4.6	Horn Signature Menu Option	30
Table 4.7	System Information Menu Option	31
Table 4.8	Alarm Log Menu Option	32

Appendix A: Manual's Revisions

Table A.1	Manual's Revisions	36
-----------	------------------------------	----

Chapter 1: Safety and Support





1.1 Safety Requirements and Warnings2
1.2 General Precautions4
1.3 How to Contact Branson6




1.1 Safety Requirements and Warnings

This chapter contains an explanation of the different safety notice symbols and icons found in this manual and provides additional safety information for ultrasonic welding. This chapter also describes how to contact Branson for assistance.

1.1.1 Symbols Found in this Manual

These symbols used throughout this manual warrant special attention:


WARNING	Indicates a possible danger
	<p>If these risks are not avoided, death or severe injury might result.</p>
WARNING	High Voltage Hazard
	<p>High voltage. Turn power off before servicing.</p>
WARNING	Corrosive Material Hazard
	<p>Corrosive material. Avoid contact with eyes and skin. Wear proper protection.</p>
CAUTION	Indicates a possible danger
	<p>If these risks are not avoided, slight or minor injury might result.</p>


CAUTION	Loud Noise Hazard
	<p>Loud noise hazard. Ear protection must be worn.</p>
CAUTION	Heavy Object
	<p>Heavy object. To avoid muscle strain or back injury, use lifting aids and proper lifting techniques.</p>
NOTICE	Indicates a possible damaging situation
	<p>If this situation is not avoided, the system or something in its vicinity might get damaged.</p> <p>Application types and other important or useful information are emphasized.</p>


1.2 General Precautions

Take the following precautions before servicing the power supply:

- Be sure the power is disconnected before making any electrical connections
- To prevent the possibility of an electrical shock, always plug the power supply into a grounded power source
- Power supplies produce high voltage. Before working on the power supply assembly, do the following:
 - Turn off the power supply
 - Unplug main power
 - Allow at least 5 minutes for capacitors to discharge
- High voltage is present in the power supply. Do not operate with the cover removed
- High line voltages exist in the ultrasonic power supply assembly. Common points are tied to circuit reference, not chassis ground. Therefore, use only non-grounded, battery-powered multimeters when testing the power supply assembly. Using other types of test equipment can present a shock hazard
- Keep hands from under the horn. Down force (pressure) and ultrasonic vibrations can cause injury
- Do not cycle the welding system if either the RF cable or converter is disconnected
- When using larger horns, avoid situations where fingers could be pinched between the horn and the fixture

CAUTION	Loud Noise Hazard
	<p>Sound level and frequency of the noise emitted during the ultrasonic assembly process may depend upon a. type of application, b. size, shape and composition of the material being assembled, c. shape and material of the holding fixture, d. welder setup parameters and e. tool design.</p> <p>Some parts vibrate at an audible frequency during the process. Some or all of these factors may result in an uncomfortable noise being emitted during the process.</p> <p>In such cases operators may need to be provided with personal protective equipment. See 29 CFR (Code of Federal Regulations) 1910.95 Occupational Noise Exposure</p>

NOTICE	
	<p>When the battery is worn out, dispose it under the ordinance of each local government.</p>

WARNING	Corrosive Material Hazard
	<p>First aid measures (in case of electrolyte leakage from the battery):</p> <p>Eye Contact: Flush the eyes with plenty of clean water for at least 15 minutes immediately, without rubbing. Get immediate medical treatment. If appropriate procedures are not taken, this may cause eye injury.</p> <p>Skin Contact: Wash the affected area under tepid running water using a mild soap. If appropriate procedures are not taken, this may cause sores on the skin. Get medical attention if irritation develops or persists.</p> <p>Inhalation: Remove to fresh air immediately. Get medical treatment immediately.</p>


1.2.1 Intended Use of the System

The DCX Power Supply and components are designed to be used as part of an ultrasonic welding system. These are designed for a wide variety of welding or processing applications.

The system can be used to perform ultrasonic welding, inserting, staking, spot welding, swaging, degating, and continuous ultrasonic operations. It is designed for automated, semi-automated and/or manual production operations.

1.2.2 Emissions

When being processed, certain plastic materials can emit toxic fumes, gases or other emissions that can be hazardous to the operator's health. Where such materials are processed, proper ventilation of the workstation is required. Check your materials suppliers for recommended protection when processing their materials.

WARNING	Corrosive Material Hazard
	<p>Processing of many materials, such as PVC, can be hazardous to an operator's health and could cause corrosion/damage to the equipment. Use proper ventilation and take protective measures.</p>

1.3 How to Contact Branson

For additional assistance, please refer to the DCX 222 RM SIG Power Supply Instruction Manual.

Chapter 2: The Web Page Interface

2.1	Introduction	8
2.2	Models Covered.....	9

2.1 Introduction

The DCX 222 RM SIG Web Page Interface provides access, via Ethernet connection, to web pages containing power supply information, diagnostics tools, and configuration options. Communication can be established point-to-point or through a local area network. On the web page interface you can access:

- [4.3 IP Setup](#)
- [4.4 Weld Preset](#)
- [4.5 I/O Diagnostics](#)
- [4.6 Seek & Weld Graphs](#)
- [4.7 Horn Signature](#)
- [4.8 System Information](#)
- [4.9 Alarm Log](#)

2.2 Models Covered

This manual applies to the web page interface of the DCX 222 RM SIG power supply.

2.2.1 DCX 222 RM SIG Power Supply Manual Set

The following documentation is available in electronic format for the DCX 222 RM SIG power supply:

DCX 222 RM SIG Power Supply Instruction Manual.

Chapter 3: Connecting to the Web Page Interface

3.1	Locating the Ethernet Port	12
3.2	System Requirements	13
3.3	Point to Point Connection (Windows 10® or Windows 11®)	14

3.1 Locating the Ethernet Port


3.1.1 DCX 222 RM SIG Ethernet Port Location


Figure 3.1 DCX 222 RM SIG Power Supply



3.2 System Requirements

To connect to the DCX Web Page Interface you will need a PC running a Windows^{®1} operating system with a Google Chrome^{™2} or Microsoft Edge^{®1} web browser software.

NOTICE	
	The DCX 222 RM SIG power supply is not compatible with network scanning software. If your local network uses these types of programs, the DCX 222 RM SIG IP address must be placed in an exclusion list.


NOTICE	
	A shielded Ethernet cable should be used to connect to the DCX 222 RM SIG Web Page Interface to prevent possible EMI (Electromagnetic Interference) issues.

-
1. Windows 10, Windows 11, and Microsoft Edge are registered trademarks of Microsoft Corporation.
 2. Google Chrome is a trademark of Google LLC.


3.3 Point to Point Connection (Windows 10® or Windows 11®)

To connect directly to the DCX Power Supply Web Page Interface using a PC with Windows 10® or Windows 11® operating system, complete the following steps:


1. Connect the power supply to a computer via the Ethernet port
2. Turn on the power supply
3. On your PC, click the Start button on the taskbar and search for the **Control Panel**
4. Select **View Large Icons** on the top right corner
5. Select **Network and Sharing Center**
6. Select **Change adapter settings**



7. Right click on **Ethernet 2** and select **Properties** to bring up the **Networking** tab




8. Highlight **Internet Protocol Version 4 (TCP/IPv4)** from the list and click on **Properties**



9. Use the following IP address:

IP address: 192.168.10.101

Subnet mask: 255.255.255.0




10. Click **OK**. Close the rest of the dialog boxes

11. Open the Google Chrome™ or Microsoft Edge® web browser

12. In the address bar type the following address: <http://192.168.10.100>. Press **Enter**

13. This will bring up the DCX 222 RM SIG Web Page Interface

14. Enter a user ID number (any number up to 9 digits long)



Chapter 4: The Web Page Interface

4.1	Web Page Interface Overview	18
4.2	Login	19
4.3	IP Setup	20
4.4	Weld Preset.	22
4.5	I/O Diagnostics.	25
4.6	Seek & Weld Graphs	27
4.7	Horn Signature	29
4.8	System Information	31
4.9	Alarm Log	32

4.1 Web Page Interface Overview

The DCX 222 RM SIG Web Page Interface allows you to set a weld preset, diagnose and configure the power supply I/O, perform horn scans and seeks, view system information, and to view and download the system alarms, history and events logs.

Figure 4.1 Web Page Interface Overview





Table 4.1 Web Page Interface Overview

Item	Name	Description
A	Menu Navigation Tabs	The menu navigation tabs are always displayed on the upper section of the web pages. They provide access to the following menu options: 4.3 IP Setup 4.4 Weld Preset 4.5 I/O Diagnostics 4.6 Seek & Weld Graphs 4.7 Horn Signature 4.8 System Information 4.9 Alarm Log
B	Menu Display	Displays the contents of the currently selected menu option.
C	Command Buttons	Different command buttons allow to save settings, cancel changes, restore default settings, and to perform other functions specific to each menu. Save, Cancel, and Restore Defaults is page specific. They only operate on the page displayed.

4.2 Login

When connection is established with the DCX 222 RM SIG Web Page Interface, the Login page will display. Enter a unique user ID number. The user ID is numeric only and up to 9 digits long. This number allows for keeping track of user access.

Figure 4.2 Login



The screenshot shows the login interface for the BRANSON DCX 222 RM SIG Web Page Interface. At the top, the BRANSON logo is displayed in red on a black background. To the right of the logo is a red 'DC' logo. Below the logo is a navigation menu with the following items: IP Setup, Weld Preset, I/O Diagnostics, Seek & Weld Graphs, Hom Signature, System Information, and Alarm Log. The main content area is titled 'LOGIN' and contains a text input field labeled 'User ID #' and a 'Log In' button.

4.3 IP Setup

Use this menu to setup the DCX 222 RM SIG power supply's network settings. The DCX 222 RM SIG power supply's default IP setting is Static IP with the address shown in the figure below.

Figure 4.3 IP Setup Menu


The screenshot shows the 'IP SETUP' menu. At the top, there is a navigation bar with 'IP Setup' selected. Below the navigation bar, the 'IP SETUP' title is displayed. The main content area contains two radio button options: 'Static IP' (selected) and 'DHCP Client'. Under 'Static IP', there are four input fields: 'IP Address' (192.168.10.100), 'Subnet Mask' (255.255.255.0), 'Gateway' (192.168.10.1), and 'MAC Address' (00-1E-C0-DE-5A-03). Below these fields is a checkbox for 'DHCP Server Enabled' which is currently unchecked. At the bottom of the form, there are three buttons: 'Save', 'Cancel', and 'Restore Defaults'.

Table 4.2 IP Setup Menu Option


Name	Description
Static IP	Select this option to manually assign an IP address to the DCX 222 RM SIG power supply. The DCX 222 RM SIG power supply will alert if an invalid IP address setting is entered.
IP Address	The IP address assigned to the DCX 222 RM SIG power supply.
Subnet Mask	The mask used to determine to what subnet the DCX 222 RM SIG power supply's address belongs to.
Gateway	The gateway address assigned to the network for communication with other computers or networks.
MAC Address	Displays the MAC address assigned to the DCX 222 RM SIG power supply.
DHCP Server Enabled	Select this option to have DCX 222 RM SIG power supply assign IP addresses to any devices connected to it. This facilitates connecting a computer or laptop point to point (P2P) with the DCX 222 RM SIG power supply. NOTICE Connecting a DCX 222 RM SIG power supply with DHCP server enabled to a network which already has a device working as a DHCP server will cause connectivity problems.

Table 4.2 IP Setup Menu Option

Name	Description
DHCP Client	Select this option to have the DCX 222 RM SIG power supply automatically request an IP address from a DHCP Server. The IP address will be grayed out.

NOTICE	
	All changes on this menu take effect on the next power-up.

At any time you may determine the DCX 222 RM SIG power supply's IP address by going through the associated registers using the front panel LCD. A Cold Start can also be performed to take your power supply back to its factory default IP address. For details on navigating the DCX 222 RM SIG registers or performing a Cold Start, consult your power supply manual.

NOTICE	
	Beware that other settings will also be reset to their defaults when a Cold Start is executed.

4.4 Weld Preset

Use this menu to set weld parameters, seek options, and power-up actions. Use the command buttons on the bottom to save settings, cancel changes, or to restore to factory default settings.

Figure 4.4 Weld Preset Menu

The screenshot shows the Branson Weld Preset Menu interface. At the top, there is a navigation bar with the Branson logo and a user status bar showing 'Current User: 12345 Logout'. Below the navigation bar, there are several menu items: IP Setup, Weld Preset (selected), I/O Diagnostics, Seek & Weld Graphs, Horn Signature, System Information, and Alarm Log. The main content area is divided into several sections:

- MODE:** Contains radio buttons for 'Continuous', 'Time(s)' (selected, with a value of 0.200), and 'Energy(J)' (with a value of 1.0).
- PEAK POWER WINDOW:** Contains radio buttons for 'Off' and 'On' (selected). Under 'On', there are checkboxes for '-Power(%)' (checked, with a value of 10) and '+Power(%)' (checked, with a value of 90).
- WELD:** Contains sub-sections for 'Amplitude' (Weld Amplitude (%) set to 80, Amplitude Ramp (ms) set to 80, and an unchecked 'External' checkbox) and 'Frequency' (Digital Tune (Hz) set to 19950, Internal Offset (Hz) set to 0). It also has checkboxes for 'End of Weld Store', 'Clear memory with Reset', 'Clear memory before Seek', and 'Set with Horn Scan'.
- SEEK:** Contains input fields for 'Seek Ramp (ms)' (80), 'Seek Time (ms)' (500), and 'Frequency Offset (Hz)' (0). It also has an unchecked 'Timed Seek' checkbox.
- POWER ON:** Contains radio buttons for 'Off', 'Seek', and 'Scan' (selected). It also has a checked 'Clear Memory' checkbox.
- MISC SETUP:** Contains checkboxes for 'Alarms - Reset Required' (checked) and 'Start Input - Handheld' (unchecked).

At the bottom of the interface, there are three buttons: 'Save', 'Cancel', and 'Restore Defaults'.

Table 4.3 Weld Preset Menu Option

Name	Description
Mode	
Continuous	Weld mode changes to Continuous after pressing save button.
Time (s)	Weld mode changes to Time after pressing save button.
Energy (J)	Weld mode changes to Energy after pressing save button.
Peak Power Window	
Off	Select this option to disable power window limits.
On	Select this option to enable power window limits.
-Power (%)	Set the desired power window limit low value. NOTICE Power window limits must be set in multiples of 5.
+Power (%)	Set the desired power window limit high value. NOTICE Power window limits must be set in multiples of 5.
Amplitude	
Weld Amplitude (%)	The amplitude of ultrasonic energy that will be delivered by the DCX 222 RM SIG power supply. Valid range is between 10 to 100 (10% to 100% amplitude).
Amplitude Ramp (ms)	The time it takes for the amplitude to ramp up to 100% when the External Start signal is applied. If amplitude setting is lower than 100%, ramp time will be adjusted accordingly.
External	Select the External check box to control the amplitude using an analog input from the user I/O connector.
Frequency	
Digital Tune (Hz)	Starting frequency set from horn signature or manually entered.
Internal Offset (Hz)	Sets the frequency offset from the Web Page as either a positive or negative value offset from digital tune.
End of Weld Store	Select to save the frequency at the end of the weld as the starting frequency for the following weld.
Clear memory with Reset	Select to clear memory with reset. Memory offset will be set to 0 when a Reset is applied. Reset can come from external I/O, front panel, or web page interface (seek or horn scan).
Clear Memory before Seek	Select to clear memory before seek. Memory offset will be set to 0 before Seek is applied.
Set with Horn Scan	Select to set Digital Tune frequency with a successfully completed horn scan.

Table 4.3 Weld Preset Menu Option

Name	Description
Seek	
Seek Ramp (ms)	The time it will take the power supply to ramp-up when performing a seek.
Seek Time (ms)	The duration of a seek.
Frequency Offset (Hz)	The frequency offset applied to the power supply operating frequency.
Timed Seek	Select this check box to have the power supply perform a seek every 60 seconds. Seeks will be timed from the moment sonics was last activated.
Power On	
Off	Select this option to disable power-on actions.
Seek	Select this option to have the power supply perform a seek on power-up.
Scan	Select this option to have the power supply perform a horn scan on power-up. If the Power On Scan fails, the User I/O overload signal will activate, the LCD alarm icon will activate, and the alarm will be logged.
Misc Setup	
Alarms - Reset Required	This option determines if the alarm is latched or not. Latched alarms require a reset before another cycle can start.
Start Input - Handheld	If this option is selected, the user must maintain the start input signal throughout the duration of the weld cycle. If the start input is released during a cycle, then the cycle is aborted.

4.5 I/O Diagnostics

Use this menu to monitor and control the DCX 222 RM SIG power supply digital and analog I/O.

Figure 4.5 I/O Diagnostics Menu




Table 4.4 I/O Diagnostics Menu Option

Name	Description
Digital Inputs	
J3-5 External Start	Indicate if the digital inputs are active.
J3-6 External Seek	
J3-13 External Reset	
Digital Outputs	
J3-2 O/L Inverted	Select/clear check boxes to toggle available digital outputs on/off.
J3-9 Sonics Active	
J3-4 Overload	
J3-1 Peak Power - Plus Limit	
J3-12 Peak Power - Minus Limit	
Analog Inputs	
J3-15 Amplitude In (V)	Displays the current analog input values.

Table 4.4 I/O Diagnostics Menu Option

Name	Description
Analog Outputs	
J3-10 Power Out (V)	Allows control of analog output values.
J3-14 Amplitude Out (V)	

4.6 Seek & Weld Graphs

Use this menu to test your system. This feature allows you to capture 5 seconds of welding data which you can both view and export. The weld data graph is provided with 6 available parameters: Amplitude, Power, Phase, PWM Amplitude, Current, and Frequency. Each parameter has a checkbox to the left of its name.

Only checked parameters will be displayed. While in this menu, if the Weld is being run from external I/O or the custom LCD, the graph can be also displayed on the screen by using the "Update Graph" button.

Figure 4.6 Seek & Weld Graphs Menu



Table 4.5 Seek & Weld Graphs Menu Option

Name	Description
Seek	
Seek	Click to perform a seek cycle.
Reset Overload	Click to reset an overload condition.
OK - Memory Stored	Indicates that the horn operating frequency was stored in the DCX 222 RM SIG power supply memory.
Overload - Cleared	Indicates that test resulted in an overload and the memory has been cleared.
Frequency	Monitors the horn operating frequency.
Memory	Displays the frequency stored in the DCX 222 RM SIG power supply memory.
Amplitude	Displays the percentage of converter amplitude.
Power	Displays the percentage of power output.
Update Graph	Click to draw the graph of last weld.
Export Graph Data	Click to export the Weld Graph data with Weld Preset settings to CSV file.
Draw from... to...	Select the <i>from</i> and <i>to</i> time values to zoom into the desired graph region.
Redraw Graph	Click to redraw the same graph with those parameters which are checked with the Time Parameter on Y axis.
Set Default	Click to return the sample rate, start time, end time and graph selection to default settings.
Graph Selection	Select a parameter and enter a particular X time value to obtain the corresponding Y value at that particular time.
Update Value	Click to update the Y value.

4.7 Horn Signature

Use this menu to diagnose your ultrasonic horn. When performing a horn scan, ideally, there will be only one resonant frequency. The Horn Signature graph is provided with 3 available parameters: Phase, Current, and Amplitude. The horn Signature Graph can be both viewed and exported.

Each parameter has a checkbox to the left of its name. Only checked parameters will be displayed.



NOTICE	
	<p>The horn scan frequency start will be 19,800Hz and the frequency stop will be 20,250Hz for the SIG Special only.</p>

Figure 4.7 Horn Signature Menu



The screenshot shows the 'HORN SIGNATURE' menu in the BRANSON software. At the top, there is a navigation bar with 'Horn Signature' selected. Below the navigation bar, there are buttons for 'Start Horn Scan' and 'Abort Horn Scan'. A 'Status' field is present, followed by 'Result' radio buttons for 'Passed', 'Failed', and 'Aborted'. To the right of the result buttons are two empty boxes labeled 'Parallel Resonant Points' and 'Series Resonant Points'. The main area contains a graph with three y-axes: 'AMPLITUDE (%)' (0-50), 'CURRENT (%)' (0-50), and 'PHASE (Deg)' (-180 to 180). The x-axis is 'FREQUENCY (Hz)' ranging from 19801 to 20251. Below the graph, there are checkboxes for 'PHASE', 'CURRENT', and 'AMPLITUDE', all of which are checked. There are also buttons for 'Update Graph' and 'Export Graph Data'. At the bottom, there is a control panel with 'Draw from 19801 Hz To 20251 Hz', 'Redraw Graph', 'Set Default', 'Graph Selection' (set to 'PHASE'), 'X Value' (19801), 'Y Value' (0), and an 'Update Value' button.

Table 4.6 Horn Signature Menu Option

Name	Description
Horn Signature	
Start Horn Scan	Click to initiate the horn scan.
Abort Horn Scan	Click to abort the horn scan.
Status	Indicates the horn scan progress.
Result	Indicates if the horn scan passed, failed, or if the operation was aborted.
Parallel Resonant Points	<p>Displays the parallel resonant frequencies of the ultrasonic horn. The parallel resonant frequency is the operating frequency of the ultrasonic stack.</p> <p>NOTICE If multiple parallel frequencies are found, they will all be listed. The frequency at which the ultrasonic stack is running will be displayed in blue.</p>
Series Resonant Points	Displays the series resonant frequencies of the ultrasonic horn.
Update Graph	Click to draw the graph of last weld.
Export Graph Data	Click to export the Weld Graph data with Weld Preset settings to CSV file.
Draw from... to...	Select the <i>from</i> and <i>to</i> time values to zoom into the desired graph region.
Redraw Graph	Click to redraw the same graph with those parameters which are checked with the Time parameter on the Y axis.
Set Default	Click to return the sample rate, start time, end time and graph selection to default settings.
Graph Selection	Select a parameter and enter a particular X time value to obtain the corresponding Y value at that particular time.
Update Value	Click to update the Y value.

4.8 System Information

Use this menu to view information about your DCX 222 RM SIG power supply. Have the information on this screen available when calling Branson for troubleshooting help.

Figure 4.8 System Information Menu




Table 4.7 System Information Menu Option

Name	Description
System	
System	Displays the DCX 222 RM SIG power supply model name.
Display	Displays the type of front panel user interface on the DCX 222 RM SIG power supply.
LCD Software Version	Displays the LCD software version number.
LCD CRC	Displays the CRC code of the LCD software.
WebSite Version	Displays the Web Page version number.
Power Supply	
Power Level	Displays the power supply wattage.
Frequency	Displays the power supply operating frequency.
Serial Number	Displays the power supply serial number.
P/S Version	Displays the power supply software version number.
CRC	Displays the CRC code of the power supply controller software.

4.9 Alarm Log

Use this screen to view the DCX 222 RM SIG power supply alarm history. The alarms can be sorted by alarm number or alarm type. Alarms can be exported to an Excel file.




Figure 4.9 Alarm Log Menu




Table 4.8 Alarm Log Menu Option

Name	Description
Alarm #	A unique alarm identification number.
Days	The DCX 222 RM SIG power supply units do not feature an integrated real time clock. Alarm date and time account for the power-on hours from the moment the DCX 222 RM SIG power supply was first turned on.
Hours	

Table 4.8 Alarm Log Menu Option

Name	Description
UserID	The ID number of the user logged in at when the alarm occurred. Will display zero if the alarm occurs from an external weld.
Data1	For future use.
Data2	
Alarm Description	
Frequency - High Seek Limit	Frequency reached high end limit: 20 kHz: 20.450 kHz
Frequency - Low Seek Limit	Frequency reached low end limit: 20 kHz: 19.450 kHz
Frequency - High Weld Limit	Frequency reached high end limit: 20 kHz: 20.450 kHz
Frequency - Low Weld Limit	Frequency reached low end limit: 20 kHz: 19.450 kHz
Overload - Current	RF current peak limit reached.
Overload - Frequency	Frequency reached high or low end limit.
Overload - Power Limit	Power supply reached 115% rated power.
Overload - Temperature	IGBT heat sink temperature limit is reached.
Overload - Voltage	RF voltage peak limit reached.
Phase Limit Time Error	When power supply out of tune phase limit error is reached after 500 ms (default time).
Command Buttons	
Clear Log	Click to clear the alarm log.
Export to Excel	Click to download an Excel spreadsheet file of the alarm log.

Appendix A: Manual's Revisions

A.1 Manual's Revisions36

A.1 Manual's Revisions

Refer to the table below for the appropriate manual revision depending on your Power Supply's manufacturing date.

Table A.1 Manual's Revisions

Manual's Revisions	Power Supply's Manufacturing Date	
	From	To
00	May 2022	March 2026
01	April 2026	To date

Figure A.1 Manufacturing date on the Information label






Figure A.2 Location of the Information label on the back of the DCX 222 RM SIG Power Supply



Index

Symbols

+Power (%) 23

A

Abort Horn Scan 30
Alarm # 32
Alarm Description 33
Alarm Log 32
Alarms - Reset Required 24
Amplitude 23, 28
Amplitude Ramp (ms) 23
Analog Inputs 25
Analog Outputs 26

C

Clear Log 33
Clear Memory before Seek 23
Clear memory with Reset 23
Command Buttons 18, 33
Contact Branson 6
Continuous 23
CRC 31

D

Data1 33
Data2 33
Days 32
DHCP Client 21
DHCP Server Enabled 20
Digital Inputs 25
Digital Outputs 25
Digital Tune (Hz) 23
Display 31
Draw from... to... 28, 30

E

Emissions 5
End of Weld Store 23
Energy (J) 23
Ethernet Port 12
Export Graph Data 28, 30
Export to Excel 33
External 23

F

Frequency 23, 28, 31
Frequency - High Seek Limit 33

Frequency - High Weld Limit 33
Frequency - Low Seek Limit 33
Frequency - Low Weld Limit 33
Frequency Offset (Hz) 24

G

Gateway 20
General Precautions 4
Graph Selection 28, 30

H

Horn Signature 29, 30
Hours 32

I

I/O Diagnostics 25
Intended Use of the System 5
Internal Offset (Hz) 23
Introduction 8, 36
IP Address 20
IP Setup 20

J

J3-1 Peak Power - Plus Limit 25
J3-10 Power Out 26
J3-12 Peak Power - Minus Limit 25
J3-13 External Reset 25
J3-14 Amplitude Out 26
J3-15 Amplitude In (V) 25
J3-2 O/L Inverted 25
J3-4 Overload 25
J3-5 External Start 25
J3-6 External Seek 25
J3-9 Sonics Active 25

L

LCD CRC 31
LCD Software Version 31
Login 19

M

MAC Address 20
Memory 28
Menu Display 18
Menu Navigation Tabs 18
Misc Setup 24
Mode 23
Models Covered 9

O

Off 23, 24
OK - Memory Stored 28
On 23
Overload - Cleared 28

- Overload - Current 33
- Overload - Frequency 33
- Overload - Power Limit 33
- Overload - Temperature 33
- Overload - Voltage 33

P

- P/S Version 31
- Parallel Resonant Points 30
- Peak Power Window 23
- Phase Limit Time Error 33
- Point to Point Connection 14
- Power 28
 - Power (%) 23
- Power Level 31
- Power On 24
- Power Supply 31

R

- Redraw Graph 28, 30
- Reset Overload 28
- Result 30

S

- Safety and Support 1
- Safety Requirements 2
- Scan 24
- Seek 24, 28
- Seek & Weld Graphs 27
- Seek Ramp (ms) 24
- Seek Time (ms) 24
- Serial Number 31
- Series Resonant Points 30
- Set Default 28, 30
- Start Horn Scan 30
- Static IP 20
- Status 30
- Subnet Mask 20
- Symbols 2
- System 31
- System Information 31
- System Requirements 13

T

- Time (s) 23
- Timed Seek 24

U

- Update Graph 28, 30
- Update Value 28, 30
- UserID 33

W

- Warnings 2
- Web Page Interface 18

WebSite Version 31
Weld Amplitude (%) 23
Weld Preset 22