Original Instructions
4000895EN - REV. 02

EMERSON



GMX-HP
Actuator

Instruction Manual

Branson Ultrasonics Corporation
120 Park Ridge Road
Brookfield, CT 06804
+86-021-3781-0588
http://www.bransonultrasonics.com

BRANSON

[This page intentionally left blank]

Manual Change Information

At Branson, we strive to maintain our position as the leader in ultrasonics plastics joining, metal welding, cleaning and related technologies by continually improving our products. These improvements are incorporated as soon as they are developed and thoroughly tested.

Information concerning any improvements will be added to the appropriate technical documentation at its next revision. Therefore, when requesting service assistance for specific units, note the revision information found on this document.

Copyright and Trademark Notice

Copyright © 2026 Branson Ultrasonics Corporation. All rights reserved. Contents of this publication may not be reproduced in any form without the written permission of Branson Ultrasonics Corporation.

[This page intentionally left blank]

Table of Contents

Chapter 1:Safety
1.1 About this manual . . . 8
1.2 Safety Information . . . 9
1.3 General Precautions . . . 11

Chapter 2:Introduction
2.1 Overview of GMX-HP . . . 16

Chapter 3:Technical Specifications
3.1 GMX-HP Configuration . . . 22
3.2 Physical Description . . . 25

Chapter 4:Installation and Setup
4.1 Handling and Unpacking . . . 28
4.2 Installation Requirements . . . 29
4.3 Installation Steps . . . 30
4.4 Electrical Connection . . . 31
4.5 Air Connection . . . 33
4.6 Automated System Connection . . . 34
4.7 Installation Dimension Drawings . . . 35

Chapter 5:Operation
5.1 Installing the Ultrasonic Stack . . . 38
5.2 Installing and Testing the Horn . . . 39
5.3 Adjusting the Air Pressure and Cylinder Speed . . . 43
5.4 Operation Preparation . . . 44

Chapter 6:Maintenance
6.1 General Maintenance Considerations . . . 46
6.2 Periodically Clean the Equipment . . . 47
6.3 Calibration . . . 48
6.4 Periodic and Preventive Maintenance . . . 49
6.5 Mechanical Limit Instruction . . . 52
6.6 Lubrication . . . 53
6.7 Spare Parts . . . 62

Chapter 7:Support
7.1 Warranty . . . 64
7.2 Contact Us . . . 65
7.3 Cybersecurity Vulnerability Reporting . . . 66

Appendix A:Diagrams and Drawings
A.1 Electrical Diagram (Interface Board) . . . 68
A.2 External View of GMX-HP . . . 69
A.3 Pneumatic System Diagram . . . 70
A.4 Force Characteristic Graph . . . 71

[This page intentionally left blank]

Chapter 1: Safety

1.1 About this manual 8
1.2 Safety Information 9
1.3 General Precautions 11

1.1 About this manual

This manual provides detailed instructions for the setup and operation of GMX-HP (hereinafter called the actuator).

The 2000Xct/2000Xdt series power supply is required to drive the actuator. For detailed information on the power supply, refer to the manual included with the power supply.

1.2 Safety Information

Observe the following safety information in these operating instructions; this information will warn you about risks and their consequences.

DANGER	Indicates an immediate danger
	If these risks are not avoided, death or severe injury will be the result.

WARNING	Indicates a possible danger
	If these risks are not avoided, death or severe injury might result.



CAUTION	Indicates a possible danger
	If these risks are not avoided, slight or minor injury might result.

NOTICE	Indicates a possible damaging situation
	If this situation is not avoided, the system or something in its vicinity might be damaged. Application types and other important or useful information are emphasized.

1.2.1 GMX-HP Actuator Labeling

NOTICE	
	Only Branson service personnel or Branson trained representatives are allowed to open, maintain and service the system. Unauthorized tampering with, modifying, or opening the unit will void the warranty.

Table 1.1 Labels on the GMX-HP Actuator

Label	Description
	**CAUTION** • **Crush Hazard** Moving parts present. Can result in serious injury to hands or fingers. Keep hands away from moving horn. • **Burn Hazard** Do not touch the tooling. • **Loud Noise Hazard** Ear protection must be worn.
	
	

1.3 General Precautions

Ensure that the installation is performed by qualified personnel and in accordance with local standards and regulation.


WARNING	
	Before installing or using this equipment, be sure to read the instruction manual, and know the warnings of safety well. When warnings are not observed, the user will be in danger of serious injury or death.

CAUTION	
	Sound level emissions over 73 dB have been measured using a standard test load. To prevent the possibility of hearing loss, use appropriate hearing protection.

CAUTION	
	Sound level and frequency of the noise emitted during the ultrasonic assembly process may depend upon a. type of application, b. size, shape and composition of the material being assembled, c. shape and material of the holding fixture, d. welder setup parameters and e. tool design. Some parts vibrate at an audible frequency during the process. Some or all of these factors may result in sound levels over 73 dB. In such cases operators may need to be provided with personal protective equipment. See 29 CFR (Code of Federal Regulations) 1910.95 Occupational Noise Exposure. For all other countries, follow your local regulations.

WARNING	
	**Shear Hazard** Moving parts can cause severe injury. Keep hands clear.

Figure 1.1 Shearing Point



1.3.1 Electrical Shock Prevention

- Check cable connection between devices when installing. If not connected correctly, there will be risk of equipment damage and electrical shock
- Do not turn on the equipment when the cover is open. You will get electrical shock when the body touches device internal parts. And, there is risk of being pinched
- Make sure that the power supply is powered off when connecting or disconnecting the converter and the RF cable
- Connect the ground line to the M4 stud of the rear control cover. If not connected, high voltage will cause electrical shock

1.3.2 Installation/Adjustment

- Do not set up this equipment in the flammable atmosphere since that there is risk of explosion
- Unplug the power plug of the power supply when installing

1.3.3 Operation

- Do not place your hands below the horn. Increased pressure or ultrasonic oscillation may injure your hands. And do not touch the vibrating horn. There is danger of being burnt
- When welding, there may be vibration in the audio frequency. In this case, please wear ear defenders
- Avoid ultrasonic vibrating horn contacting with the metallic spacer and jigs. It may cause equipment damage.

- Do not press the test switch of the power supply, and do not start the cycle when the converter or the RF cable is not connected. High voltage is present in the case, when contacting with the body, it will cause electrical shock and equipment damage

1.3.4 Repair

- When the equipment break down, do not use it until repair and adjustment has been finished
- If convert the control circuit and wiring carelessly, malfunction will occur, the operator may get injured
- High voltage is present in the converter, and it may cause electrical shock. When repairing, Branson specified engineers are at your service
- Do not disassemble the equipment or do additional processing. Machine performance will be weakened. When somewhat conversion is necessary please contact your local Branson representative and service engineer

1.3.5 Intended Use of the System

The GMX-HP components are designed to be used as part of an ultrasonic welding system. These are designed for a wide variety of welding or processing applications.

If the equipment is used in a manner not specified by Branson, the protection provided by the equipment may be impaired.

Branson Ultrasonics Corporation designs and manufactures machines giving the first priority to safety precautions, to allow customers to use the machines safely and effectively. Only trained personnel should operate or service the equipment. Untrained operators can misuse the equipment or ignore safety instructions that can result in personal injury or equipment damage. It is essential that all operators and service personnel pay attention to safety instructions when operating and servicing the equipment.

GMX-HP is intended to be integrated to other devices or automation. It is not intended for standalone operation as a benchtop system.

1.3.6 Setting up the Workplace

Measures for setting up a workplace for safe operation of the ultrasonic welder are outlined in Chapter 4: Installation and Setup.

[This page intentionally left blank]

Chapter 2: Introduction

2.1 Overview of GMX-HP 16

2.1 Overview of GMX-HP

The actuator is the compact, rigid unit used in the automated system. It is connected to the Branson 2000Xct/2000Xdt-series power supply.

The actuator is available in the following configurations:

- Actuator (pressure mechanism) mounted on the base. This is called the stand
- Standalone actuator removed from the base and is used in the automated system (GMX-HP)

The actuator contains all the necessary air units. The air pressure sensor, the load cell (increased pressure sensor) and the linear encoder (position sensor) provide detailed information on operations.

You can use the power supply to monitor the actuator's settings. With the exception of the downspeed and air pressure, you can configure the actuator's settings from the power supply.

2.1.1 Carriage and Slide Mechanism

After steel carriage, booster and horn stack is assembled, dovetailed clamp is used to install the assembly onto the linear guide and it is activated by the air cylinder. This slide system ensures the accuracy of the horn position, smooth linear movement, and long-term reliability.

2.1.2 Horn quick-change device

Due to the special working conditions of the horn, irregular maintenance or replacement is required. The unique horn quick-change device of this machine is simple and safe to operate, saves labor and time, and provides a strong guarantee for efficient and stable production.

2.1.3 Air Pressure Mechanism

The air pressure mechanism is installed in the actuator (pressure mechanism), and is composed of the solenoid valve, the air cylinder, the pressure gauge, and the pressure regulator. You can use the knob speed regulating valve on the front panel to control the horn downspeed, while the speed controller above the cylinder can be used to control the up-speed.

The actuator is equipped with an analog air pressure sensor, which is mounted on the board. This sensor monitors air pressure during operation. The pressure values are sent to the 2000Xct/2000Xdt power supply during monitoring and at the end of each welding cycle, and are displayed on the display.

2.1.4 Dynamic Trigger and Dynamic Follow Through

In many welding applications, pressure must be applied to the workpiece before triggering ultrasonics. For this reason, the actuator is equipped with a load cell (increased pressure sensor) that is located beneath the air cylinder. This cell monitors the pressure applied to the workpiece. To trigger ultrasonics, a predetermined pressure should be applied to the part.

The load cell uses the pressure values to:

- Determine the timing for triggering ultrasonics
- Create a graph of the pressure during operation as a function of time
- Determine the minimum and maximum pressure values

To ensure quality of welding, the dynamic follow through stabilizes the pressure placed on the workpiece being welded.

The dynamic trigger and the dynamic follow through are performed in the following manner:

When the welder receives the start signal, the solenoid valve in the actuator activates and supplies air to the upper part of the cylinder. This causes the horn to move down and make contact with the workpiece. Then, load cell values are read while pressure is applied to the workpiece. When the pressure value is equal to the value predetermined by the 2000Xct/2000Xdt power supply and the horn is positioned within the specified area (by the linear encoder as described in the next section), the signal is then sent to the power supply to trigger ultrasonics.

After metal welding starts, pressure applied to the workpiece is kept stable. This enables the repulsion of the spring in the dynamic trigger mechanism to maintain the smooth and effective transmission of ultrasonic energy.

NOTICE	
	The minimum stroke must be at least 20 mm.

2.1.5 Linear Encoder

The linear encoder measures the distance the horn has traveled. Depending on the power supply settings, it can:

- Allow for distance welding
- Detect improper setup controls
- Monitor the quality of the weld

CAUTION	
	You cannot use the unit if the upper limit switch (described in the next section) does not turn off at the end of the stroke. Even if you turn the switch on, starting the next cycle before the carriage (horn) returns to the home position may change the absolute value and affect welding.

2.1.6 Upper Limit Switch

The optical upper limit switch (ULS) tells the power supply that the carriage (horn) has returned to the home (ULS) position and is ready for the next operation cycle. The next cycle is then ready to start. This switch activates when the distance from the upper limit of the stroke to the carriage is 3.2 mm or less.

The upper limit switch position is the starting point for the linear encoder count. The counter is reset to zero when the upper limit switch turns on.

2.1.7 Cooling the Converter

Exposing the piezoelectric ceramic elements of the converter to temperatures exceeding 60°C (140°F) can affect the performance and reliability of the converter. Make sure that the ambient temperature of the converter front driver does not exceed 50°C (122°F) during operation.

WARNING	
	Before handling the converter or measuring the temperature, make sure that ultrasonics have been deactivated.

The converter has the male hose nipple to which the cooling air tube is connected. (The inner diameter of the air tube is 1/4 inch.)

To check if the converter is being operated near the maximum allowable temperature, perform one of the following procedures:

- Place the surface temperature probe on the front driver of the converter assembly. Wait until the temperature reading stabilizes. If the reading is above 48°C (120°F), the converter must be cooled
- If you do not have a temperature probe, use your hand to check the temperature of the converter front driver. If the converter feels hot, it must be cooled

WARNING	
	During the high duty cycle, the converter must be cooled further. The average system power must be adjusted to less than the maximum continuous power that is specified. If the proper OFF time keeps the power under the upper limit during the average continuous duty cycle, it is OK for the peak power to exceed the maximum allowable power for 10 seconds or less. During the 20 kHz/2500 W continuous duty cycle, the maximum power is about 1600 W.

To cool the converter, perform the following procedure:

1. Supply at least 50psi (340kPa) of clean dry air through the 0.060inch (inner diameter) orifice
2. Perform a welding operation
3. Immediately after you finish the welding operation, check the converter temperature
4. Continue to use a different orifice with a progressively wider diameter until the converter temperature is below 48°C (120°F)


Using 50 psi (340 kPa) of air for a 0.060 inch orifice, you can obtain a readout of 80 ft3/h (24.4 m3/h). This value is sufficient to cool the converter during most operations that require air flow.

2.1.8 Cooling the Horn

During a continuous welding operation or applications that are longer than the duty cycles, it may be necessary to cool the horn. During the welding cycle, this unit supplies the horn cooling air from the accordion nozzle located on the side. The cooling settings at the power supply allow you to change the air blow cycle. Closing the cock stops the air supply.

2.1.9 GMX-HP Automation Integration Example

It is integration of GMX-HP to other devices or automation. It is not intended for standalone operation as a benchtop system. After integration into other equipment or automation, start/emergency stop and safety protection are provided by other equipment or automation suppliers.



The following picture shows the integrated GMX-HP Welder station.

Includes:

1. GMX-HP welder system
2. Exterior protective enclosure/door
3. Start/emergency stop button
4. other



[This page intentionally left blank]

Chapter 3: Technical Specifications

3.1 GMX-HP Configuration 22
3.2 Physical Description 25

3.1 GMX-HP Configuration

Table 3.1 GMX-HP Configuration

Feature	Description
Cylinder Diameter/ Stroke	ø125mm 100 mm (20-95 mm valid)
Horn Up/Down Speed	The speed is adjusted by using the speed controllers mounted in the front of the unit and above the cylinder.
Nodal Support	Hold the booster nodal tightly by clamp to make linkage between booster and cylinder to minimize the shake between the horn and the booster.
Horn quick-change device	Through the safety quick-change interface with guide function, the entire module formed by the horn and the clamping mechanism can be quickly and safely connected to or removed from the actuator.
Filter Regulator	The filter removes dust and water. The regulator sets the welding pressure supplied to the cylinder. (This unit is equipped with a precision regulator.)
Pressure Sensor	Used to set the welding pressure and provides judgment basis for ultrasonic on/ off.
Solenoid Valve for Activating the Horn	The unit houses a solenoid valve for horn travel. This valve is controlled by the power supply.
Lower Limit Stopper	The stopper adjusts the lower limit to which the horn travels.
Upper Limit Switch	The optical upper limit switch (ULS) tells the power supply that the horn has returned to the home position and is ready for the next operation cycle.
Linear Encoder	The encoder is the optical sensor that measures the distance the carriage has traveled.
Return Spring	This compression coil spring is used to return the carriage to the home position.

3.1.1 GMX-HP Specifications

NOTICE	
	All specifications are subject to change without notice.

Table 3.2 GMX-HP Specifications

Feature	Description
Horn Up/Down Speed	The speed is adjusted by using the speed controllers mounted in the front of the unit and above the cylinder.
Maximum Effective Pressure	6500 N @ Max. 0.55Mpa AIR PRESSURE
Factory Air	0.5 MPa clean dry air, 5 µm
Machine Parts	Copperless (excluding certain parts and the conducting material)
Power Supply	24 VDC is provided by the 2000Xct/2000Xdt power supply.

3.1.2 Environmental Specifications

Table 3.3 Environmental Specifications

Environmental Condition	Acceptable Range
Ambient Operating Temperature	+5°C to +50°C
	+41°F to +122°F
Storage / Shipping Temperature	-25°C to +55°C
	-13°F to +131°F
Operating Altitude	2000 m
	6561 ft
Humidity	30% to 95% non-condensing

3.1.3 Compatibility

Table 3.4 Compatibility

Power Supply	2000Xct/2000Xdt series (20 kHz) power supply
Converter	105 (connector type)
Booster	AMTECH polar mount booster

CAUTION	
	The converter must always be used with a compatible power supply. Failure to do so can result in electrical damage.

3.2 Physical Description

NOTICE	
	Dimensions are nominal.

Table 3.5 Dimensions and Weights of the GMX-HP Actuator

Width	Height	Depth	Weight
510.25 mm	978 mm	613.6 mm	270 Kg
20.1 in	38.5 in	24.16 in	595.3 lb

For detailed dimensional information refer to section A.2 External View of GMX-HP.

[This page intentionally left blank]

Chapter 4: Installation and Setup

4.1 Handling and Unpacking 28
4.2 Installation Requirements 29
4.3 Installation Steps 30
4.4 Electrical Connection 31
4.5 Air Connection 33
4.6 Automated System Connection 34
4.7 Installation Dimension Drawings 35

4.1 Handling and Unpacking

GMX-HP actuator units are carefully checked and packed before dispatch. It is recommended, however, that you follow the inspection procedure below after delivery.

Table 4.1 Handling and Unpacking

Step	Instructions
1	Check the equipment immediately after delivery to ensure that they have not been damaged during transport.
2	Verify that all parts are complete according to the delivery note.
3	Determine if any component has become loose during shipping and, if necessary, tighten screws.

NOTICE	
	If the goods delivered have been damaged during shipping, please contact the forwarding agent immediately. Retain packing material (for possible inspection or for sending back the unit).

CAUTION	
	The actuator and the controller are heavy. Handling, unpacking, and installation might require assistance of a colleague or the use of a lifting device.

4.2 Installation Requirements

1. Install the actuator away from air conditioners and heat vents.
2. The actuator should be installed in the following environment:

Table 4.2 Environmental Specifications

Environmental Condition	Acceptable Range
Ambient Operating Temperature	+5°C to +50°C
	+41°F to +122°F
Storage / Shipping Temperature	-25°C to +55°C
	-13°F to +131°F
Operating Altitude	2000 m
	6561 ft
Humidity	30% to 95% non-condensing

4.3 Installation Steps

The actuator is fixed to the aluminum frame for transportation. Take out the lock bolt, move the actuator to the installation location, and then mount it on the rigid base. Tighten the four screws at the bottom (M10 bolts).


CAUTION	
	The GMX-HP actuator is heavy and can cause a pinching or crushing injury during installation or adjustment. Keep clear of moving parts and do not loosen clamp unless directed to do so. Handling, unpacking, and installation can require help or the use of lifting platforms or hoists. Use the lifting points to interface with lifting equipment. **Figure 4.1** Lifting Points 

Table 4.3 Lifting Points Location

Item	Description
1	Lifting Point

CAUTION	
	Do not mount the actuator on an unstable workbench or other insecure location. Failure to do so may cause the actuator to fall or move unexpectedly.

1. Verify that there is no interference among the devices.
2. The actuator is equipped with the coupler 20PM plug that is connected to the air supply source. Insert the plug into the socket.

4.4 Electrical Connection

Two cables connect the power supply and the actuator: the actuator interface cable, and the RF cable. The automation system requires a J911 start cable, a start and emergency stop system, and a user I/O cable connected to the user control circuit.

Details about the ports in the rear of the actuator is as below.

Table 4.4 Electrical Connection

Step	Instructions
1	Use the J925 interface cable to connect the 37-pin D-Sub connector on the actuator rear panel and the 37-pin D-Sub connector located at the rear of the power supply.
2	Use the J931 RF cable to connect the 3-pin RF connector for the converter and the 3-pin connector located at the rear of the power supply.
3	Use the J911 start cable to connect the BASE/ Start 9-pin connector on the rear panel of the actuator.
4	Tighten the screws securely.

Figure 4.2 Ports in the rear of the actuator




Table 4.5 Ports in the rear of the actuator

Item	Description	Item	Description
1	Actuator P/S Port	5	Remote Pneumatics Port
2	GDS Port	6	RF and Cooling Fan Port
3	Start and Emergency Stop Signal Ports	7	Air Inlet Port
4	Linear Encoder Port		

4.4.1 Start and E-Stop Ports Signal Definition Diagram and Start Cable J911 Pins Diagram

Figure 4.3 Start and Emergency Stop Ports Signal Definition Diagram




Figure 4.4 J911 Start Cable Pins Diagram

J911 Start Cable Pin Wire Color:

CONNECTIONS	
PIN NO.	WIRE COLOR
1	BLK
2	WHT
3	RED
4	GRN
5	BRN
6	BLU
7	ORG
8	YEL
9	PUR
HOUSING	SHIELD

START and E- STOP contacts can be used as a safety interlocks when GMX-HP integrated to other device. Both respond to category 3, PL d according to EN 13849-1. START contacts can also be used to start GMX-HP welding cycle. This START signal must be held ON until actuator will contact welding parts (trigger activated).

4.5 Air Connection

The air supply must be clean (to a 5 micron level), dry and unlubricated air with a regulated maximum pressure of 0.7 MPa.

CAUTION	
	The air supply must not exceed 0.6 MPa. Otherwise, damage to the devices may occur. Set the pressure gauge to zero before connecting/disconnecting air supply.

Supply the factory air to the actuator. Start from zero, and gradually raise the air supply pressure.

NOTICE	
	The air supply switch should be supplied by customer.

This clean actuator is equipped with a central exhaust port for air connection. The air filter exhaust port is screwed into place. If needed, you can connect the port.

CAUTION	
	Properly connect each port appropriately. Failure to do so may cause the actuator to operate abnormally.


4.6 Automated System Connection


Refer to the power supply instruction manual for details on the automated system connection.

WARNING	
	Please review the following precautions before installing and operating the actuator. 1. Keep hands out from under the horn. Do not touch or look inside the horn when it is vibrating. Down force (pressure) and ultrasonic vibrations can cause injury 2. Some large plastic parts vibrate at an audible frequency during welding. To prevent injury, take soundproofing measures and other precautions 3. Make sure that the vibrating horn is not in contact with the metal base or the fixture. It may cause equipment damage 4. Do not push the test switch of the power supply and do not start the cycle when the converter and the RF cable is not connected. There is high voltage in the case, when touch the body, electrical shock and equipment damage will be caused

4.7 Installation Dimension Drawings


Figure 4.5 INSTALLATION DIMENSION WITH BASE SUPPORT





INSTALLATION DIMENSION WITH BASE SUPPORT
（带底座安装尺寸）

Figure 4.6 INSTALLATION DIMENSION WITHOUT BASE SUPPORT



Chapter 5: Operation

5.1 Installing the Ultrasonic Stack 38
5.2 Installing and Testing the Horn. 39
5.3 Adjusting the Air Pressure and Cylinder Speed. 43
5.4 Operation Preparation. 44

5.1 Installing the Ultrasonic Stack

Connect converter, booster, balance bars and horn as shown in the figure below by a torque spanner. Specific torques are required between each connection. The reference values are as follows:

Table 5.1 Torque Values

Component	Torque Value
Converter to Booster	55 ft-lbs
Booster to Balance Bar	70 ft-lbs
Balance Bar to Balance Bar	95 ft-lbs

Figure 5.1 Double Push Full-wave Ultrasonic Stack





Figure 5.2 Single Push Full-wave Ultrasonic Stack



5.2 Installing and Testing the Horn

The GMX-HP can be fitted with at least two ultrasonic stacks, the following describes the installation process for a double push full-wave ultrasonic stack and a single push full-wave ultrasonic stack respectively.

Table 5.2 Installing and Testing the double push full-wave ultrasonic stack



Step	Instructions
1	BRANSON provides an assembly module with horn, as shown in Figure 5.3, including black horn, gray components, and green clamp. Special attention: Since the assembly of the horn and the gray components requires high positioning accuracy and consistency, specific tooling or inspection tools are required to ensure the stability and reliability of the final welding. If you need to replace different horn specifications, the corresponding parts may also need to be replaced or adjusted accordingly, please contact BRANSON professionals for guidance and installation. Unauthorized operation may cause damage to the horn or related components, and even affect the final welding stability and quality. **Figure 5.3** 
2	For the installation of the assembly module with the horn and the booster, as shown in Figure 5.4, first loosen the nuts and screws on the side of the golden component, and loosen 4~5 turns to ensure that the assembly module with the horn can be smoothly installed and exit. Then remove two M10 screws on the front and remove the fixing block through which the screws pass. Next, fully install the assembly module with the horn along the guide notch below the gold component. Next, tighten the screws on the side of the golden components to ensure that the assembly module with the horn does not shake, and then tighten the nuts. Finally, fix the fixing block in front of it completely with the 2 M10 screws removed earlier, and tighten the nuts on the side again and make a mark. **Figure 5.4** 

Table 5.2 Installing and Testing the double push full-wave ultrasonic stack





Step	Instructions
3	For the installation of the booster, as shown in Figure 5.4 above, after the second step is completed, remove two M6 screws of the green clamp, and take out the lower half of the clamp. Then tighten the red booster and black horn in place according to the aforementioned torque. Then fix the lower half of the green clamp with the two M6 screws removed earlier, and at the same time ensure that the booster is freely clamped on the plane perpendicular to the axis of the horn, and is only subject to axial tightening.
4	For the installation of the convertor, as shown in Figure 5.5 below, fix the silver-gray convertor with the black horn and the red booster from left to right according to the aforementioned torque. **Figure 5.5** 

Table 5.3 Installing and Testing the single push full wave ultrasonic stack

Step	Instructions
1	Same as the installation of double push full wave ultrasonic stack. BRANSON provides an assembly module with horn, as shown in Figure 5.6, including black horn, gray components, and green clamp. Special attention: Since the assembly of the horn and the gray components requires high positioning accuracy and consistency, specific tooling or inspection tools are required to ensure the stability and reliability of the final welding. If you need to replace different horn specifications, the corresponding parts may also need to be replaced or adjusted accordingly, please contact BRANSON professionals for guidance and installation. Unauthorized operation may cause damage to the horn or related components, and even affect the final welding stability and quality. **Figure 5.6** 
2	For the installation of the assembly module with the horn and the booster, as shown in Figure 5.7, first loosen the nuts and screws on the side of the golden component, and loosen 4~5 turns to ensure that the assembly module with the horn can be smoothly installed and exit. Then remove two M10 screws on the front and remove the fixing block through which the screws pass. Next, fully install the assembly module with the horn along the guide notch below the gold component. Next, tighten the screws on the side of the golden components to ensure that the assembly module with the horn does not shake, and then tighten the nuts. Finally, fix the fixing block in front of it completely with the 2 M10 screws removed earlier, and tighten the nuts on the side again and make a mark.Note that when the full-wave single push is used, the convertor is compatible with both left and right sides, and users can configure them according to actual use requirements. When it is placed on the right side, it is the same as the installation method of the double push full-wave ultrasonic stack. Only the case where it is placed on the left side is described here. **Figure 5.7** 

Step	Instructions
3	For the installation of the booster, as shown in Figure 5.7 above, after the second step is completed, remove two M6 screws of the green clamp, and take out the lower half of the clamp. Then tighten the red booster and black horn in place according to the aforementioned torque. Then fix the lower half of the green clamp with the two M6 screws removed earlier, and at the same time ensure that the booster is freely clamped on the plane perpendicular to the axis of the horn, and is only subject to axial tightening.
4	For the installation of the convertor, as shown in Figure 5.8 below, fix the silver-gray convertor from the left to the red booster with the aforementioned torque.
5	For the installation of the balance bar, as shown in Figure 5.8 below, fix the silver-gray balance bar from the right to the black horn with the aforementioned torque. **Figure 5.8** 

5.3 Adjusting the Air Pressure and Cylinder Speed

The pressure of the air supplied to the cylinder increases when the regulator is turned clockwise, and the value is read in the pressure gauge. When adjusting the regulator, always start with an air pressure that is lower than the desired setting, and then gradually raise the pressure. When you use the regulator to lower the air pressure, the supply pressure readout may not be correct. This is because the pressure gauge is affected by the additional pressure in the cylinder.

The horn downspeed increases when you turn the speed control on front panel of the unit counterclockwise; the horn stops when you turn the controller clockwise to the limit. Changing the air pressure also changes the downspeed. Make sure to adjust the downspeed after you finish setting the air pressure. And make sure to adjust the decreasing speed (downspeed) after you adjusting the increasing speed (upspeed).

5.4 Operation Preparation

Actuator is controlled by the 2000Xct/2000Xdt power supply. Actuator sends the cycle data of velocity, pressure etc. and alarm information to the power supply, based on the data and information, power supply decides start/stop time of welding and sends operation parameters to the actuator.

In actuator, we can only set air pressure, velocity and mechanical stop. For other settings, please use power supply.

The equipment is operational when the following three connections are finished: cable connection between actuator and power supply (in case of automatic system, including start and I/O connection), air supply connection, power connection to power supply. Perform welding setup as the following procedure.

Table 5.4 Operation Preparation

Step	Instructions
1	Adjust the regulator handle of actuator until air pressure equals the setting pressure. (Confirm the air gauge)
2	Turn on the power switch of power supply, the power light indicating that actuator is powered on lights up. And the main menu is displayed in the power supply display.
3	Select the horn down switch on the main menu. It comes to be able to drive the actuator. Press the start switch (input start signal), horn moves down. When want horn up, press the rising switch on the display. Adjust the mechanical stop (4.2) and down speed by repeating this operation. (Down speed is displayed on the display.) And the system pressure (setting pressure) can be confirmed on the display, when advanced setting is necessary, adjust by operating the regulator
4	Set various welding parameters when all above settings are finished. Then start welding.

For advanced setting of power supply, welding result and all other navigations, please refer to power supply instruction manual.

WARNING	
	Do not place your hands below the horn. And do not touch or look into the vibrating horn. Increased pressure or ultrasonic oscillation may injure you.

WARNING	
	Avoid the ultrasonic vibrating horn contacting with metallic spacer and jigs. It may cause equipment damage.

WARNING	
	When the system is running, only one person can operate it.

Chapter 6: Maintenance

6.1 General Maintenance Considerations 46
6.2 Periodically Clean the Equipment 47
6.3 Calibration 48
6.4 Periodic and Preventive Maintenance 49
6.5 Mechanical Limit Instruction 52
6.6 Lubrication 53
6.7 Spare Parts 62

6.1 General Maintenance Considerations

NOTICE	
	There are no customer replaceable components inside the system. Have all servicing done by a qualified Branson technician.

NOTICE	
	When performing maintenance on the welder, make sure that no other automated systems are active.

WARNING	
	Use LOTO (Lock Out Tag Out) lockable plug cover over line cord plug during any maintenance.

6.2 Periodically Clean the Equipment

6.2.1 External Covers

External covers may be cleaned with a damp sponge or cloth using a solution of mild soap and water. Do not allow cleaning solution to enter the unit.

To prevent rust in areas of high humidity, exposed steel surfaces, may require a very light film of rust preventing oil.

6.3 Calibration

The actuator does not normally require a regularly scheduled full system calibration. However, if you significantly change the welding conditions or you need to recalibrate the actuator because of a calibration error, make sure to contact your Branson representative before performing recalibration. Regularly obtain information to check whether the oscillation version has been upgraded.

6.4 Periodic and Preventive Maintenance

The following preventive measures will help ensure long term operation of your Branson Actuators.

6.4.1 Periodically Clean the Equipment

Periodically disconnect the unit from power, remove the cover and vacuum out any accumulated dust and debris. Remove material adhering to the circuit boards, cooling intake vents and exhaust ports. Periodically disconnect the airline from the air supply, open the air filter and clean the element and bowl with mild soap and water. External covers may be cleaned with a damp sponge or cloth using a solution of mild soap and water. Do not allow cleaning solution to enter the unit. Exposed steel surfaces, such as handles, hardware and the main column may require a very light film of oil, such as WD-40, to prevent rust in areas of high humidity.

6.4.2 Recondition the Stack (converter, booster, and horn)

Stack components function with greatest efficiency when the mating interface surfaces are in proper condition. For 15kHz, 20kHz and 30kHz products, a Branson Mylar washer should be installed between the horn and the booster, and booster and converter. Replace the washer if torn or perforated. We recommend that stacks using Mylar washers be inspected every three months.

Stacks used with silicone grease, as with certain 20 kHz installations and with all 40 kHz products, should be periodically reconditioned to eliminate fretting corrosion. We recommend that a stack using silicone grease be inspected every two weeks for corrosion. The inspection interval can then be adjusted longer or shorter as required, when experience is gained for specific stacks. See the Branson instruction manuals for correct stack interface reconditioning procedures.

NOTICE	
	The operating efficiency of the equipment will be greatly affected if the mating interfaces of the converter, booster, and horn are not flat, make poor contact with each other, or become corroded. A poor contact condition wastes power and makes tuning difficult. It may also affect the noise level and damage the converter.

To recondition the interfaces:

1. Remove the stack from the actuator.
2. Disassemble the converter, booster, and horn stack. Observe the following rules:
3. In the event that you must disassemble a Stack, always use the correct spanner wrench and a suitable soft-faced vise to remove a horn or booster, and reverse the procedures described earlier in this Section.

CAUTION	
	NEVER attempt to remove a horn or booster by holding the converter housing or booster clamp ring in a vise.

NOTICE	
	Use a soft-jawed vise (brass or aluminum) to remove square or rectangular horns, or horns otherwise unremovable.

4. Wipe the interfaces with a clean cloth or paper towel.
5. Examine all interfaces. If any interface is corroded or shows a dark, hard deposit, it should be reconditioned.
6. If the interfaces appear to be in good condition, go to step 13.
7. If necessary, remove the coupling studs.
8. Tape a clean sheet of #400 grit (or finer) emery cloth to a clean, smooth flat surface. A piece of glass is suitable.
9. Hold the part to be conditioned at its lower end and carefully stroke it in one direction across the emery cloth. Do not press down. the weight of the component provides enough pressure.
10. Perform a second stroke. Rotate the part 1/3 around and stroke it twice across the cloth.

NOTICE	
	Use no more than two strokes in one position. Use the same number of strokes at each location.

11. Turn the part the remaining 1/3 and repeat.
12. Re-examine the interface and repeat steps 8, 9, and 10 until the surface appears clean and smooth. This should not take more than 2 or 3 complete rotations of the part being reconditioned.
13. Clean the threaded hole, using a clean cloth or paper towel.
14. Replace the stud with a new one if removed. Torque the 3/8-24 studs to 290 inch pounds (32.77 Nm). Torque 1/2-20 studs to 450 inch pounds (50.84 Nm).Torque M8x1-1/4 studs to 70 inch pounds (7.9 Nm).

NOTICE	
	The use of a Branson torque wrench or the equivalent is recommended. P/N 101-063-787 for 20kHz systems and 101-063-618 for 40kHz systems.

CAUTION	
	Failure to follow torque specifications may cause the stud to loosen or break, and the system to overload. The use of a Branson torque wrench or equivalent is required.

15. Reassemble the stack and install it in the actuator.

6.4.3 Routine Component Replacement

The lifetime of certain parts is based on the number of cycles the unit has completed, or on hours of operation. Table 6.1 lists the average number of hours or cycles one should use in determining when components should be replaced. Ambient operating temperature also affects lifetime. Higher temperatures reduce the number of cycles and hours before replacement is suggested. The charts below are for equipment operating at a temperature of 72 to 75°F (22 - 24° C).

The lifetime of system pneumatic components is influenced by the quality of the compressed air provided. All Branson systems require clean, dry, (normal) factory compressed air. When oil or moisture is present in the compressed air, the lifetime of the pneumatic components will be reduced. This table lists pneumatic parts with an average factory compressed air condition.

Table 6.1 Component Replacements Based on Cycles Run

Interval	Component Replacements
At 10 Million Cycles	Air Cylinder
	Hydraulic snubber
At 40 Million Cycles	Solenoid Valves
	Pressure Regulator
	Air Filter
	Cooling Valve
	S-Beam Load Cell Assembly
	Encoder Assembly
	Linear Bearing (2" stroke or greater)

For Reference Purposes:

1. A system operating at 60 welds per minute, 8 hours per day, 5 days per week, 50 weeks per year completes approximately 7.2 million cycles in 2000 hours.
2. The same system at 24 hours per day, 5 days per week, in 50 weeks completes 21.6 million cycles in 6000 hours.
3. 24 hours per day, 365 days per year produces 31.5 million cycles in 8760 hours.

Please note that parts replaced during preventive maintenance constitute normal wear and tear. They are not covered by warranty.

6.5 Mechanical Limit Instruction

The mechanical limit device of GMX-HP is shown in the figure below. Its function is to protect the motion mechanism from overshooting, which may damage the life of main components and may affect the stability of the system.


Special attention:

The mechanical limit of each BRANSON welding machine has a factory-set standard. Users are not allowed to change the settings here for other non-design purposes. Branson will not bear the corresponding responsibility for the loss of relevant parts or other related damage caused by changing the design purpose of the mechanical limit, and will not be counted into the warranty scope of the whole machine.

GMX-HP mechanical limit related parts mainly refer to the following parts:

1. Ruler
2. Limited rod
3. Flange nut
4. Stop screw
5. Lock nut

Figure 6.1




6.6 Lubrication

Table 6.2 Lubrication Plan

Product	GMX-HP
EDP-Linear Guide	1032229
Grease Nipple	B-M6F
Grease Gun	MG70+TYPE H
Lubricate type	AFB-LF Grease-THK or equivalent
Dosage	2~4g/Block
Method of Lubrication	Manual fat-feeding
Maintenance Interval	Add grease based on every 100KM

When integrated to the automation system, please shut down the equipment for maintenance at the specified time.

Figure 6.2 AFB-LF Grease



Lubrication
AFB-LF Grease

THK Original Grease
AFB-LF Grease
●Base oil: refined mineral oil
●Consistency enhancer: lithium-based

AFB-LF Grease is a general-purpose grease that provides excellent extreme pressure performance and mechanical stability properties through the use of a refined mineral oil base oil and a lithium-based consistency enhancer.


[Features]
(1) Extreme pressure resistance
The action of the special additives provides higher wear resistance and extreme pressure resistance than other lithium-based greases available on the market.
(2) Mechanical stability
AFB-LF Grease is not easily softened and demonstrates excellent mechanical stability even when used for a long period of time.
(3) Long service life
It provides many times the lubrication life of general lithium soap-based greases. As a result, it offers a lower maintenance workload and greater economy due to the longer intervals between greasing.

[Representative Physical Properties]

Item		Representative value	Test method
Consistency enhancer		Lithium-based	
Base oil		Refined mineral oil	
Base oil kinematic viscosity: mm²/s (40℃)		170	JIS K 2220 23
Worked penetration (25℃, 60 W)		275	JIS K 2220 7
Mixing stability (100,000 W)		345	JIS K 2220 15
Dropping point: ℃		193	JIS K 2220 8
Evaporation amount: mass% (99℃, 22 h)		0.4	JIS K 2220 10
Oil separation rate: mass% (100℃, 24 h)		0.6	JIS K 2220 11
Copper plate corrosion (B method, 100℃, 24 h)		Accepted	JIS K 2220 9
Low-temperature torque: mN-m (-20℃)	Starting	130	JIS K 2220 18
	Rotational	51	
4-ball testing (welding load): N		3089	ASTM D2596
Service temperature range: ℃		-15 to 100	
Color		Brownish yellow	

Accessories for Lubrication

Figure 6.3 Grease Gun






Figure 6.4 AFB-LF SDS

SAFETY DATA SHEET

1. Identification

Product identifier AFB-LF GREASE

Other means of identification

SDS number 1030-T20483-1

Product code AFB-LF+70, AFB-LF+400

Recommended use Industrial lubricating grease (Package size 70gr and 400gr)

Recommended restrictions None known.

Manufacturer/Importer/Supplier/Distributor information

THK Co.,LTD
HEAD OFFICE: 2-12-10, Shibaura, Minato-ku, Tokyo 108-8506 Japan
THK America, Inc.: 200 E. Commerce Drive, Schaumburg, IL 60173, U.S.A.
Telephone: (847) 310-1111 (THK America) between the hours of 8 am - 5 pm
Emergency telephone: (847) 310-1111 (THK America) between the hours of 8 am - 5 pm
E-mail: chicago@thk.com, thk022@thk.co.jp

2. Hazard(s) identification

Physical hazards	Not classified.	
Health hazards	Serious eye damage/eye irritation	Category 1
Environmental hazards	Hazardous to the aquatic environment, acute hazard	Category 3
	Hazardous to the aquatic environment, long-term hazard	Category 3
OSHA defined hazards	Not classified.	

Label elements



Signal word Danger

Hazard statement Causes serious eye damage. Harmful to aquatic life with long lasting effects.

Precautionary statement

Prevention Wear eye/face protection. Avoid release to the environment.

Response If in eyes: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Immediately call a poison center/doctor.

Storage Store away from incompatible materials.

Disposal Dispose of contents/container in accordance with local/regional/national/international regulations.

Hazard(s) not otherwise classified (HNOC) Not classified.

Supplemental information None.

3. Composition/information on ingredients

Mixtures

Chemical name	CAS number	%
Distillates (petroleum), solvent-dewaxed heavy paraffinic	Proprietary	10 - 30

Distillates (petroleum), hydrotreated heavy naphthenic	Proprietary	10 - 20
Distillates (petroleum), solvent-refined heavy naphthenic	Proprietary	10 - 20
Residual oils (petroleum), solvent-refined	Proprietary	10 - 20
Phosphorodithioic acid, O,O-di-C1-14-alkyl esters, zinc salts	Proprietary	3.2 - 4.0
Amines, C12-14-alkyl, reaction products with hexanol, phosphorus oxide (P2O5), phosphorus sulfide (P2S5) and propylene oxide	Proprietary	0.1 - 1.0

*Designates that a specific chemical identity and/or percentage of composition has been withheld as a trade secret.

Composition comments * All concentrations are percent by weight unless ingredient is a gas. Gas concentrations are in percent by volume.

4. First-aid measures

Inhalation Move affected person into fresh air and keep warm. If breathing is difficult, give oxygen. Get medical attention if any discomfort continues.

Skin contact Remove contaminated clothing. Wash with soap and water. Get medical attention if irritation develops and persists.

Eye contact Immediately flush with plenty of water for at least 15 minutes. If easy to do, remove contact lenses. Get medical attention promptly if symptoms occur after washing.

Ingestion Immediately rinse mouth and drink plenty of water. Never give anything by mouth to an unconscious person. Get medical attention if any discomfort continues.

Most important symptoms/effects, acute and delayed Severe eye irritation.

Indication of immediate medical attention and special treatment needed Treat symptomatically. The effects might be delayed.

General information First aid personnel must be aware of own risk during rescue.

5. Fire-fighting measures

Suitable extinguishing media Extinguish with foam, carbon dioxide or dry powder.

Unsuitable extinguishing media Do not use water or halogenated extinguishing media.

Specific hazards arising from the chemical Thermal decomposition may produce smoke, oxides of carbon and lower molecular weight organic compounds whose composition have not been characterized.

Special protective equipment and precautions for firefighters Selection of respiratory protection for firefighting: follow the general fire precautions indicated in the workplace. Self-contained breathing apparatus, operated in positive pressure mode and full protective clothing must be worn in case of fire.

Fire fighting equipment/instructions Use standard firefighting procedures and consider the hazards of other involved materials. Containers close to fire should be removed or cooled with water.

General fire hazards The product is not flammable.

6. Accidental release measures

Personal precautions, protective equipment and emergency procedures Avoid contact with skin and eyes. Wear suitable protective clothing, gloves and eye/face protection. In case of spills, beware of slippery floors and surfaces. For personal protection, see section 8 of the SDS.

Methods and materials for containment and cleaning up Absorb spillage with non-combustible, absorbent material. Clean contaminated area with oil-removing material.

Environmental precautions Do not contaminate water. Contact local authorities in case of spillage to drain/aquatic environment.

7. Handling and storage

Precautions for safe handling Avoid contact with skin and eyes. Always remove grease with soap and water or skin cleaning agent, never use organic solvents. Wear appropriate personal protective equipment. Be aware of potential for surfaces to become slippery. Observe good industrial hygiene practices.

Conditions for safe storage, including any incompatibilities Keep container in a well-ventilated place. Store away from incompatible materials.

8. Exposure controls/personal protection

Occupational exposure limits

US. OSHA Table Z-1 Limits for Air Contaminants (29 CFR 1910.1000)

Components	Type	Value	Form
Distillates (petroleum), hydrotreated heavy naphthenic	PEL	5 mg/m3	Mist.
Distillates (petroleum), solvent-dewaxed heavy paraffinic	PEL	5 mg/m3	Mist.
Distillates (petroleum), solvent-refined heavy naphthenic	PEL	5 mg/m3	Mist.
Residual oils (petroleum), solvent-refined	PEL	5 mg/m3	Mist.

US. ACGIH Threshold Limit Values

Components	Type	Value	Form
Distillates (petroleum), hydrotreated heavy naphthenic	TWA	5 mg/m3	Inhalable fraction.
Distillates (petroleum), solvent-dewaxed heavy paraffinic	TWA	5 mg/m3	Inhalable fraction.
Distillates (petroleum), solvent-refined heavy naphthenic	TWA	5 mg/m3	Inhalable fraction.
Residual oils (petroleum), solvent-refined	TWA	5 mg/m3	Inhalable fraction.

US. NIOSH: Pocket Guide to Chemical Hazards

Components	Type	Value	Form
Distillates (petroleum), hydrotreated heavy naphthenic	Ceiling	1800 mg/m3	
	STEL	10 mg/m3	Mist.
	TWA	5 mg/m3	Mist.
Distillates (petroleum), solvent-dewaxed heavy paraffinic	Ceiling	1800 mg/m3	
	STEL	10 mg/m3	Mist.
	TWA	5 mg/m3	Mist.
Distillates (petroleum), solvent-refined heavy naphthenic	Ceiling	1800 mg/m3	
	STEL	10 mg/m3	Mist.
	TWA	5 mg/m3	Mist.
Residual oils (petroleum), solvent-refined	STEL	10 mg/m3	Mist.
	TWA	5 mg/m3	Mist.

Biological limit values No biological exposure limits noted for the ingredient(s).

Exposure guidelines No exposure standards allocated.

Appropriate engineering controls	Provide adequate ventilation and minimize the risk of inhalation of vapors and oil mist. Provide access to washing facilities including soap, skin cleanser and fatty cream.
Individual protection measures, such as personal protective equipment	
Eye/face protection	Wear approved safety goggles.
Skin protection	
Hand protection	Wear protective gloves. Nitrile gloves are recommended, but be aware that the liquid may penetrate the gloves. Frequent change is advisable. Suitable gloves can be recommended by the glove supplier.
Skin protection	
Other	Wear appropriate clothing to prevent repeated or prolonged skin contact.
Respiratory protection	In case of inadequate ventilation or risk of inhalation of oil mist, suitable respiratory equipment with particulate filter and organic vapor cartridges can be used. If engineering controls do not maintain airborne concentrations below recommended exposure limits (where applicable) or to an acceptable level (in countries where exposure limits have not been established), an approved respirator must be worn. Use a NIOSH/MSHA approved air purifying respirator as needed to control exposure. Consult with respirator manufacturer to determine respirator selection, use, and limitations. Use positive pressure, air-supplied respirator for uncontrolled releases or when air purifying respirator limitations may be exceeded. Follow respirator protection program requirements (OSHA 1910.134 and ANSI Z88.2) for all respirator use.
Thermal hazards	When material is heated, wear gloves to protect against thermal burns.
General hygiene considerations	Always observe good personal hygiene measures, such as washing after handling the material and before eating, drinking, and/or smoking. Routinely wash work clothing and protective equipment to remove contaminants.

9. Physical and chemical properties

Appearance	Buttery.
Physical state	Solid.
Form	Buttery.
Color	Tan.
Odor	Mild.
Odor threshold	Not available.
pH	Not available.
Melting point/freezing point	Not available.
Initial boiling point and boiling range	Not available.
Flash point	370.4 °F (188.0 °C) Setaflash Closed Cup (ISO 3679)
Evaporation rate	Not available.
Flammability (solid, gas)	Not available.
Upper/lower flammability or explosive limits	
Flammability limit - lower (%)	Not available.
Flammability limit - upper (%)	Not available.
Vapor pressure	Not available.
Vapor density	Not available.
Relative density	0.9 g/cm3
Solubility(ies)	
Solubility (water)	Not available.
Partition coefficient (n-octanol/water)	Not available.
Auto-ignition temperature	Not available.
Decomposition temperature	Not available.
Viscosity	Not available.

10. Stability and reactivity

Reactivity	The product is stable and non-reactive under normal conditions of use, storage and transport.

Chemical stability	Stable at normal conditions.
Possibility of hazardous reactions	Will not occur.
Conditions to avoid	Heat, sparks, flames, elevated temperatures.
Incompatible materials	Strong oxidizing agents.
Hazardous decomposition products	Carbon oxides. Sulfur oxides. Phosphorus oxides. Formaldehyde. PAH (polycyclic aromatic hydrocarbons).

11. Toxicological information

Information on likely routes of exposure

Inhalation	Inhalation of oil mist or vapors formed during heating of the product will irritate the respiratory system and provoke coughing.
Skin contact	May cause skin irritation.
Eye contact	Prolonged contact causes serious eye and tissue damage.
Ingestion	Ingestion may cause irritation and malaise.
Symptoms related to the physical, chemical and toxicological characteristics	Extreme irritation of eyes and mucous membranes, including burning and tearing.

Information on toxicological effects

Acute toxicity	The harmful effects may increase when exposed to used grease. Ingestion may cause irritation and malaise.
Skin corrosion/irritation	Causes mild skin irritation.
Serious eye damage/eye irritation	Causes serious eye damage.
Respiratory or skin sensitization	
Respiratory sensitization	None known.
Skin sensitization	None known.
Germ cell mutagenicity	None known.
Carcinogenicity	Prolonged and repeated contact with used grease may cause serious skin diseases, such as dermatitis and skin cancer.

IARC Monographs. Overall Evaluation of Carcinogenicity

Not listed.

NTP Report on Carcinogens

Not listed.

OSHA Specifically Regulated Substances (29 CFR 1910.1001-1053)

Not listed.

Reproductive toxicity	None known.
Specific target organ toxicity - single exposure	None known.
Specific target organ toxicity - repeated exposure	None known.
Aspiration hazard	None known.
Chronic effects	None known.

12. Ecological information

Ecotoxicity	Harmful to aquatic life with long lasting effects.
Persistence and degradability	None known.
Bioaccumulative potential	None known.
Mobility in soil	Not available.
Mobility in general	The product contains substances, which are insoluble in water and which may spread on water surfaces.
Other adverse effects	Not available.

13. Disposal considerations

Disposal instructions	Dispose of in accordance with local regulations.

Waste from residues / unused products	Dispose in accordance with applicable federal, state, and local regulations. Dispose of in accordance with local regulations.
Contaminated packaging	Since emptied containers retain product residue, follow label warnings even after container is emptied.

14. Transport information

DOT

Not regulated as dangerous goods.

IATA

Not regulated as dangerous goods.

IMDG

Not regulated as dangerous goods.

Transport in bulk according to Annex II of MARPOL 73/78 and the IBC Code	Not available.

15. Regulatory information

US federal regulations — This product is a "Hazardous Chemical" as defined by the OSHA Hazard Communication Standard, 29 CFR 1910.1200.

TSCA Section 12(b) Export Notification (40 CFR 707, Subpt. D)

Not regulated.

CERCLA Hazardous Substance List (40 CFR 302.4)

Phosphorodithioic acid, O,O-di-C1-14-alkyl esters, zinc salts (CAS Proprietary) — Listed.

SARA 304 Emergency release notification

Not regulated.

OSHA Specifically Regulated Substances (29 CFR 1910.1001-1053)

Not listed.

Toxic Substances Control Act (TSCA)

Superfund Amendments and Reauthorization Act of 1986 (SARA)

SARA 302 Extremely hazardous substance

Not listed.

SARA 311/312 Hazardous chemical	Yes
Classified hazard categories	Serious eye damage or eye irritation

SARA 313 (TRI reporting)

Not regulated.

Other federal regulations

Clean Air Act (CAA) Section 112 Hazardous Air Pollutants (HAPs) List

Not regulated.

Clean Air Act (CAA) Section 112(r) Accidental Release Prevention (40 CFR 68.130)

Not regulated.

Safe Drinking Water Act (SDWA)	Contains component(s) regulated under the Safe Drinking Water Act.

US state regulations

US. Massachusetts RTK - Substance List

Distillates (petroleum), hydrotreated heavy naphthenic (CAS Proprietary)
Distillates (petroleum), solvent-dewaxed heavy paraffinic (CAS Proprietary)
Distillates (petroleum), solvent-refined heavy naphthenic (CAS Proprietary)

US. New Jersey Worker and Community Right-to-Know Act

Distillates (petroleum), hydrotreated heavy naphthenic (CAS Proprietary)
Distillates (petroleum), solvent-dewaxed heavy paraffinic (CAS Proprietary)
Distillates (petroleum), solvent-refined heavy naphthenic (CAS Proprietary)
Phosphorodithioic acid, O,O-di-C1-14-alkyl esters, zinc salts (CAS Proprietary)

US. Pennsylvania Worker and Community Right-to-Know Law

Distillates (petroleum), hydrotreated heavy naphthenic (CAS Proprietary)

Distillates (petroleum), solvent-refined heavy naphthenic (CAS Proprietary)
Phosphorodithioic acid, O,O-di-C1-14-alkyl esters, zinc salts (CAS Proprietary)

US. Rhode Island RTK

Distillates (petroleum), hydrotreated heavy naphthenic (CAS Proprietary)
Distillates (petroleum), solvent-dewaxed heavy paraffinic (CAS Proprietary)
Distillates (petroleum), solvent-refined heavy naphthenic (CAS Proprietary)

California Proposition 65

California Safe Drinking Water and Toxic Enforcement Act of 2016 (Proposition 65): This material is not known to contain any chemicals currently listed as carcinogens or reproductive toxins. For more information go to www.P65Warnings.ca.gov.

US. California. Candidate Chemicals List. Safer Consumer Products Regulations (Cal. Code Regs, tit. 22, 66502.3, subd. (a))

Distillates (petroleum), hydrotreated heavy naphthenic (CAS Proprietary)
Distillates (petroleum), solvent-dewaxed heavy paraffinic (CAS Proprietary)
Distillates (petroleum), solvent-refined heavy naphthenic (CAS Proprietary)

International Inventories

Country(s) or region	Inventory name	On inventory (yes/no)*
Australia	Australian Inventory of Chemical Substances (AICS)	Yes
Canada	Domestic Substances List (DSL)	Yes
Canada	Non-Domestic Substances List (NDSL)	No
China	Inventory of Existing Chemical Substances in China (IECSC)	Yes
Europe	European Inventory of Existing Commercial Chemical Substances (EINECS)	Yes
Europe	European List of Notified Chemical Substances (ELINCS)	Yes
Japan	Inventory of Existing and New Chemical Substances (ENCS)	Yes
Korea	Existing Chemicals List (ECL)	Yes
New Zealand	New Zealand Inventory	No
Philippines	Philippine Inventory of Chemicals and Chemical Substances (PICCS)	Yes
Taiwan	Taiwan Chemical Substance Inventory (TCSI)	Yes
United States & Puerto Rico	Toxic Substances Control Act (TSCA) Inventory	Yes

*A "Yes" indicates this product complies with the inventory requirements administered by the governing country(s).
A "No" indicates that one or more components of the product are not listed or exempt from listing on the inventory administered by the governing country(s).

16. Other information, including date of preparation or last revision

Issue date 04-September-2013

Revision date 07-May-2019

Version # 04

Further information HMIS® is a registered trade and service mark of the NPCA.

HMIS® ratings Health: 3
Flammability: 0
Physical hazard: 0

NFPA ratings



List of abbreviations

Disclaimer This information is provided without warranty. The information is believed to be correct. This information should be used to make an independent determination of the methods to safeguard workers and the environment.

Copyright © THK CO., LTD. All rights reserved.

6.7 Spare Parts

Table 6.3 Recommended Spare Parts List (GMX-HP)

EDP	Description
200-099-190R	SWITCH OPTICAL
102-242-963	ASSY PCBD AED/AEF CNTRL EN13849
100-143-161R	ENCODER 4 METRIC
1018782	ASSY S-BEAM
1016765	INDICATOR DP
1016766	ASSY VAVLE DP
1016768	ASSY AIR REGULATOR DP
1016769	REGULATOR DP
1031593	PRESSURE INDICATOR DP
1032229	LINEAR GUIDE GMX-HP
1032232	SPRING GMX-HP
1016795	ASSY AIR FILTER DP
1033909	CYLINDER GMX-HP

Chapter 7: Support

7.1 Warranty 64
7.2 Contact Us 65
7.3 Cybersecurity Vulnerability Reporting 66

7.1 Warranty

For warranty information please reference the warranty section of Terms and Conditions found at: https://www.branson.emerson.com/en/branson-terms-conditions.

7.2 Contact Us



Our dedicated experts are here to assist you with any questions or concerns you may have, ensuring you get the help you need.

Visit https://www.emerson.com/en/corporate/contact-us to find the technical support information, documentation, and software updates you need for your Emerson products and systems.

7.3 Cybersecurity Vulnerability Reporting


If you discover a potential vulnerability, please report it to us using the dedicated contact channel: Branson.PSIRT@emerson.com or via the reporting form available at https://emerson.com/reportvulnerability.

Appendix A: Diagrams and Drawings

A.1 Electrical Diagram (Interface Board) 68
A.2 External View of GMX-HP 69
A.3 Pneumatic System Diagram. 70
A.4 Force Characteristic Graph 71


A.1 Electrical Diagram (Interface Board)

Figure 8.1 Electrical Diagram (Interface Board) (EDP 1034417)




A.2 External View of GMX-HP

Figure 8.2 External View of GMX-HP




A.3 Pneumatic System Diagram

Figure 8.3 Pneumatic System Diagram (EDP 1035101)



A.4 Force Characteristic Graph

Figure 8.4 Force Characteristic Graph



*The recommended pressure range of the system: 0.05 Mpa-0.55 Mpa.

*When the air pressure is set to 0.05 MPa, the stroke shall not exceed 60 mm.

[This page intentionally left blank]

Original Instructions
4000895EN - REV. 02

EMERSON



Branson Ultrasonics Corporation
120 Park Ridge Road
Brookfield, CT 06804
(203) 796-0400
http://www.bransonultrasonics.com

Copyright © 2021 Branson Ultrasonics Corporation. All rights reserved. Contents of this publication may not be reproduced in any form without the written permission of Branson Ultrasonics Corporation.

BRANSON